MODEL 301 INSTALLATION DETAILS

CAUTION!



FIRMLY HOLD THE SERVICE FITTINGS WITH A 1-3/8" WRENCH WHEN MAKING THE SERVICE CONNECTION. DO NOT ALLOW THE FITTING AND/OR BARREL TO TURN OR TWIST

INSTALLATION NOTES:

- 1. REMOVE AND DISCARD THE 6" SECTION OF PVC PIPE PRTECTING THE INLET FITTING. THIS SECTION OF PIPE IS FOR SHIPPING PURPOSE ONLY.
- 2. WHEN INSTALLING, 1/2(APPROXIMATELY 4") OF THE BASE OF THE ENCLOSURE SHOULD BE BURIED BELOW THE FINISHED GRADE.
- 3. WATER PLUS RECOMMENDS ENCASING THE BASE OF THE ENCLOSURE WITH 6" X 6" POURED CONCRETE CURB OR COMPACTING 3/8" MINUS CRUSHED STONE AROUND THE BASE OF THE ENCLOSURE. SEE DRAWING.
- 4. WHEN MAKING THE INLET CONNECTION, THE SERVICE FITTING MUST BE FIRMLY HELD WITH A 1-3/8" WRENCH, WHEN TIGHTENING THE COMPRESSION (PACK) NUT. DO NOT ALLOW THE BARREL OF THE SAMPLING STATION TO TWIST OR TURN. SEE CAUTION DETAIL.

